




PLAY 2

TRUE WIRELESS HEADSET

РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ

Благодарим за выбор продукта uBear!
Просим внимательно ознакомиться с данной инструкцией
перед использованием.




1.	Сенсорная кнопка управления
2.	Микрофоны
3.	Индикатор заряда
4.	Зарядный кейс

■ Перед использованием

1. Примерьте амбушюры в комплекте. Выберите те, которые будут для Вас наиболее комфортными и обеспечат наилучшее звучание.



2. Расположите наушник так, как показано на рисунке ниже. Слегка поверните наушник в разные стороны, чтобы найти наиболее удобное положение.



■ Начало использования

1. Чтобы подключить наушники к Вашему телефону или другому устройству, выньте их из кейса.
2. Включите функцию Bluetooth на Вашем устройстве, найдите "PLAY2" в Bluetooth меню и подключитесь. Вы услышите "connected".
3. После первого использования, наушники будут подключаться к данному устройству автоматически.


■ Начало использования

1. Вы можете управлять прослушиванием музыки, используя сенсорную кнопку на наушниках:
 - Для вызова голосовой помощи, коснитесь правого наушника трижды.
 - Коснитесь один раз, чтобы поставить на паузу и еще один раз, чтобы продолжить воспроизведение.
 - Дважды коснитесь правого наушника для перехода к следующей аудиозаписи.
 - Дважды коснитесь левого наушника для возврата к предыдущей аудиозаписи.
 - Длительное касание правого наушника позволит увеличить громкость.
 - Длительное касание левого наушника позволит уменьшить громкость.

■ Звонки

1. Во время звонка, используйте сенсорную кнопку на любом наушнике.
 - Коснитесь один раз, чтобы ответить на входящий звонок или удерживайте в течение 3 секунд, чтобы отклонить звонок.
 - Коснитесь один раз для завершения звонка.

■ Зарядка кейса



1. Подключите кейс к Вашему ПК, портативному аккумулятору или сетевому зарядному устройству (5V*1A или 5V*1.5A), используя Micro-USB кабель в комплекте.
2. Во время зарядки, индикатор начнет мигать голубым.
3. Когда кейс полностью заряжен, индикатор перестает мигать.
4. После полной зарядки отсоедините кейс.

■ Зарядка наушников

1. Положите наушники в кейс.
2. Во время зарядки индикаторы на наушниках будут гореть зеленым.
3. Индикаторы погаснут, как только наушники будут полностью заряжены.
4. За 2 минуты до того, как батарея Ваших наушников будет полностью разряжена, Вы будете слышать "battery low" каждые 30 секунд.

■ Спецификация

■ Общая спецификация наушников:

Модель:	Беспроводные True Wireless наушники PLAY 2
Размер:	23.6×16.3×23.7мм
Вес:	4.5г
Зарядный ток:	55mA
Время зарядки:	1 час
Рабочее напряжение:	3.3V~4.2V
Время работы в режиме ожидания:	около 40 часов
Время работы в режиме прослушивания музыки:	3~3.5 часа
Время работы в режиме разговора:	3~3.5 часа
Bluetooth версия:	4.2
Поддерживаемые Bluetooth профили:	HSP, HFP, A2DP, AVRCP
Диапазон передачи(Гц):	2.40GHz ~ 2.48ГГц
Расстояние передачи:	10м
Поддерживаемые аудио форматы:	CVSD, MSBC, SBC, AAC
SNR:	>95дБ
Допустимая температура в режиме работы:	-15°C~+60°C
Допустимая влажность в режиме работы:	10%-85% (не замороженном виде)

■ Спецификация динамика:

Диаметр:	Ф6мм
Импеданс:	16Ωм
Частота (Гц):	20Гц~20КГц
Чувствительность:	93±3дБ
Потребляемая мощность:	2.0mW (стандартная), 5mW (макс)

■ Спецификация микрофона:

Тип микрофона:	Silicon MIC
Чувствительность:	-42±3дБ
Звуковое давление:	130дБ

■ Общая спецификация кейса:

Размер:	59.5*34.5*27.3мм
Вес:	27.6г
Разъем:	Micro USB
При полном заряде кейса наушники можно зарядить:	2 раза
Время зарядки:	1-2 часа
Входное напряжение:	5V
Зарядный ток:	250 mA
Выходное напряжение:	5V

■ Защита от неисправностей

Устройство оснащено системами защиты от короткого замыкания, перенапряжения, перегрева, чрезмерной зарядки и разрядки.



■ Меры предосторожности

Внимательно ознакомьтесь с инструкцией перед использованием продукта.

1. Не подвергать наушники и кейс воздействию высокой температуры, а также прямых солнечных лучей. Использовать вдали от открытого огня или нагревательных элементов
2. Избегать механических повреждений устройства. При обнаружении каких-либо повреждений, деформации или коррозии, прекратить использование устройства и связаться с производителем или сдать устройство в ближайший пункт по утилизации.
3. Не разбирать устройство, не модифицировать.
4. Не подвергать воздействию влаги. Хранить в сухом месте.
5. Использовать только кабель, прилагаемый к устройству или кабель Micro USB высокого качества.
6. Не использовать поврежденный кабель.
7. Неправильное использование устройства может привести к нагреву, воспламенению продукта и серьезным травмам. В случае возникновения неисправностей, прекратить использование и свяжитесь с поставщиком.
8. Контролируйте громкость, чтобы не допустить негативного воздействия на Ваш слух. Избегайте прослушивания громкой музыки в течение длительного времени: это может привести к ухудшению или потере слуха.
9. Контролируйте свою безопасность во время использования наушников. (Например, во время вождения или занятий спортом)

Мы приложили все усилия для того, чтобы информация в данном руководстве пользователя была максимально точной и полной. Неправильное использование продукта может привести к повреждению продукта, избыточному нагреву, возгоранию или взрыву, а также привести к серьезным травмам или материальному ущербу, за которые uBear (Производитель) не несет ответственности. uBear оставляет за собой право вносить любые изменения без дальнейших уведомлений в любые продукты.

■ Комплектация



- ▲ Зарядный кейс
- ▲ Силиконовые амбушюры
- ▲ Наушники PLAY
- ▲ Зарядный кабель Micro-USB
- ▲ Инструкция по эксплуатации

■ Техническая поддержка и гарантии

Просим обращаться на сайт www.ubear-world.com за технической поддержкой. Гарантийная информация представлена в размещенной ниже гарантийной карточке.

uBear Inc. California

28 Valley st, Office 1045, Pasadena, CA 91105, USA Website

www.ubear-world.com

Phone +13238253023

E-Mail info@ubear-world.com

Гарантийный талон

Условия

1. Продукция uBeag подлежит гарантийному обслуживанию (включая материалы и качество изготовления) в течение 12 месяцев со дня покупки.
2. uBeag не предоставляет гарантийные услуги в любом из следующих случаев: дефект был вызван: неправильным использованием, небрежностью, несчастным случаем, неправильным использованием; несанкционированным ремонтом или модификацией товара; неподходящим электрическим напряжением или неправильным соединением.
3. Все гарантийные услуги будут оказываться только после предоставления гарантийного талона для оригинальных продуктов, а также документа, подтверждающего покупку (чек) в том же регионе, где необходимо предоставить данную услугу.
4. Если в течении гарантийного срока поставка каких-либо деталей для продукта была прекращена, замена может быть произведена подходящими деталями другой модели.
5. uBeag оставляет за собой право изменять условия без предварительного уведомления.




PLAY 2

TRUE WIRELESS HEADSET

USER MANUAL

Thanks for your support to uBear! Please, read the guide for maintenance carefully in order to protect your legal interests.




1.	Music & Call sensor button
2.	Microphones
3.	Charging indicator
4.	Charging case

■ Before using

1. Try all ear tips to find the best fit and the best sound. It should feel comfortable and provide with best quality and loudest sound.



2. Please put the earphones to your ears correctly as it is shown on the photo. Twist them a little to find the comfortable variant.



■ Start using

1. To connect your earphones with your devices, pick out them from the case. The earphone will switch on automatically and flash green.
2. Turn on Bluetooth on your device and find "PLAY 2" in the Bluetooth menu and connect it. You will hear "connected".
3. After first time the earphones will connect your device automatically.


■ Playing music

1. You can control playing to music using the touch buttons on your earphones:
 - To wake up the voice assistant, touch the right earphone three times.
 - Touch once to pause a track, touch again to resume.
 - Double-touch the left earphone to go to previous track.
 - Double-touch the right earphone to go to the next track.
 - Long-touch the left earphone to make the volume -.
 - Long-touch the right earphone to make the volume +.

■ Calls

1. When making and answering calls, you can touch on the earbud.
 - Touch once to answer an incoming call, or Long Touch for 3 seconds to reject it.
 - Once to end a call.

■ Charging the case



1. Connect the case to your PC, power bank or wall charger (5V¹A or 5V¹.5A) using Micro-USB cable included.
2. The indicator of the case flashes blue, while charging.
3. The indicator stops flashing when fully charged.
4. Disconnect the case when fully charged.

■ Charging earphones

1. Put them to the case.
2. When charging the indicators on the earphones lights green
3. When fully charged the indicator turns off.
4. When the battery level is only for 2 minutes, you will hear "battery low" in the earphones every 30 seconds.

■ Specification

■ Basic Specifications of Earphone:

Model:	PLAY 2 True Wireless Headset
Size:	23.6×16.3×23.7mm
Weight:	4.5g
Earbuds Charging Current:	55mA
Earbuds Charging time:	1 hour
Working Voltage:	3.3V~4.2V
Standby time:	about 40 hours
Music Time:	3~3.5 hours
Talking Time:	3~3.5 hours
Bluetooth version:	Bluetooth 5.0
Support Bluetooth Profile:	HSP, HFP, A2DP, AVRCP
Transmission Range (Hz):	2.40GHz ~ 2.48GHz
Transmission distance:	10m
Audio encoding format:	CVSD, MSBC, SBC, AAC
SNR:	>95dB
Working temperature:	-5℃~+60℃
Working humidity:	10%~85% (in a non-frozen state)

■ Earbud Speaker Specifications:

Speaker specifications mode:	Φ6mm
Impedance:	16Ω/ TYP.
Frequency(Hz):	20Hz~20KHz
Sensitivity:	93±3dB
Input Power:	2.0mW (Normal), 5mW (Maximum)

■ Earbud MIC Specifications:

MIC type:	Silicon MIC
MIC sensitivity:	-42±3dB
SPL:	130dB

■ Basic Specifications of Charging Case:

Size:	59.5°34.5°27.3mm
Weight:	27.6g
Charging Port:	Micro USB
Charging base(Full) provide power to earphone:	2 times
Charging time :	1-2hrs
Input Voltage :	DC5V
Charging current:	250 mA
Output Voltage:	DC5V

■ Trouble Shooting

The earphone headset is protected from short circuit, overvoltage protection, temperature protection, overcharge and overdischarge protection.



■ Trouble Shooting

Read all the instructions and warnings carefully prior to using this product.

1. Do not store the earphones in a high temperature environment, including intense sunlight heat. Do not place charger near the fire or other excessively hot environment
2. Avoid excessive drops, bumps, abrasions or other impacts to this product. If there is any damage to the earphones such as dents, punctures, tears, deformities or corrosion, due to any cause, discontinue use and contact Manufacturer or dispose of it in an appropriate manner at your local recycling center.
3. Do not disassemble this product or attempt to repair or modify it in any manner.
4. Do not expose these earphones to moisture or submerge it in liquid. Keep it dry at all time.
5. Please, use only the cable included or any high quality USB-A – Micro USB cable.
6. Do not use damaged cable.
7. Incorrect use of the Earphone headset can cause the it to get hot, ignite, and can cause serious injury. Due to any cause listed, discontinue use the product and contact Manufacturer.
8. To avoid hearing damage, keep the volume at a moderate level. Avoid listening to music at loud volume levels for prolonged periods of time as this may cause permanent earing damage or hearing loss.
9. Do not use earphones when it is unsafe to do so. For example, while operating a vehicle, cycling, crossing a road, or any activity which requires your attention and ability to hear.
10. If you are watching video while using your earbuds, your audio may be slightly out of sync with your device.

We have made every effort to ensure that the information and procedures in this user manual are accurate and complete. Improper use of this product may result in product damages, excess heat, fire or explosion, and cause serious injury or property damage, for which uBear (Manufacturer) is not responsible. uBear reserves the right to make any changes without further notices to any products herein.

■ Package Content



- ▲ Charging case
- ▲ Eartips
- ▲ PLAY earphones
- ▲ Micro-USB Charging cable
- ▲ User manual

■ Technical Support and Warranty

Please refer to www.ubear-world.com for technical support and the included warranty card for warranty information.

uBear Inc. California

28 Valley st, Office 1045, Pasadena, CA 91105, USA Website

www.ubear-world.com

Phone +13238253023

E-Mail info@ubear-world.com

WARRANTY CARD



Terms and Conditions

1. uBear products are subject to a warranty period (including materials and workmanship) of 12 months from the date of purchase.
2. uBear is not responsible for the repairing or replacement of products in any of the following circumstances: the defect was caused: by misuse, negligence, accident, abuse, improper installation, and misapplication; unauthorized attempts to repair or modify the product; incorrect or inadequate electrical voltage or connection.
3. All warranty services will only be provided upon presentation of the original products warranty Card with proof of purchase (dealer's receipt or invoice) in the same region where the servicing is brought in to the uBear Service Centre or its authorized service agent.
4. During the warranty period if the supply of any parts of the defect items are discontinued, customers are required to trade in the defect items for other equivalent version products.
5. uBear reserves all the rights to alter the terms and conditions without prior notice-